

V-CYMBAL DIGITAL
RIDE

CY-18DR

Owner's Manual



V·Drums

Before using this unit, carefully read "USING THE UNIT SAFELY" and "IMPORTANT NOTES" (p. 4). After reading, keep the document(s) where it will be available for immediate reference.

Copyright © 2016 ROLAND CORPORATION

English

日本語

Deutsch

Français

Italiano




Español

Português


Nederlands

Check the Included Items

After opening the package, check that all of the included items are present. If anything is missing, contact your dealer.

CY-18DR		Connection cable
Wing nut		Cable tie
Felt washer		Owner's manual (this document)
Stopper		

CY-18DR Components



(*1) This button will be used in the event of a future upgrade.


* It is not normally used.

Making the Settings


Mounting on the Stand

1. Use a commercially available drum key to tighten the stopper bolt.

The stopper keeps the V-Cymbal from turning, preventing the tangling of cables on the stand.




2. Attach the V-Cymbal, while positioning it so the Roland logo is located on the side opposite the performer.



3. Tighten the included felt washer and the wing nut to obtain the desired movement.


- * Use the included felt washer and wing nut.
- * Double sounding may occur if the wing nut is loose.

4. Insert the plug of the connection cable into the CY-18DR's DIGITAL TRIGGER OUT connector.



5. Secure the cables in place with the cable tie.

Leave some slack in the cables to ensure they are not pulled by the movement of the V-Cymbal pads.



1. Be sure to make this small plastic hook visible from you.

Wind a cable tie around a cable.

2. Wind a cable tie around the pipe and tighten it in order to not to slip.

Insert the small plastic hook to a hole to secure the cable to the cymbal arm.

- * Take care to ensure that the cables do not touch the V-Cymbal pads and/ or the stand. A cable touching a V-Cymbal pad or a stand may cause double sounding or other incorrect operation.

Connecting to the Drum Sound Module

Use a Roland drum sound module that supports digital connections.

1. Insert the plug of the connection cable into the drum sound module's DIGITAL TRIGGER IN port.
2. On the drum sound module, make settings for using the CY-18DR.

* For details, refer to the owner's manual of your drum sound module.

Recommended settings for the trigger parameters

The first time you connect the CY-18DR to your drum sound module, the recommended values are assigned to the trigger parameters.

You may need to adjust the trigger parameters depending on how you've mounted the CY-18DR and the location at which you've installed it.

For details on editing refer to the owner's manual of your drum sound module.





Playing Method

The response to various playing methods depends on the drum sound module.

For details, refer to the owner's manual of your drum sound module.

NOTE

- Use only wooden or plastic sticks. Using a carbon or metal stick may cause the sensor to malfunction.
- Use nylon brushes. Using metal brushes may cause the sensor to malfunction, and may scratch the pad.

Playing method	Explanation
<p>Bow shot</p> <p>Nuance changes depending on the strike location</p> 	<p>This is the most common playing method, playing the middle area of the cymbal. It corresponds to the sound of the "head-side" of the connected trigger input.</p>
<p>Edge shot</p>  <p>Edge sensor</p>	<p>This playing method involves striking the edge with the shoulder of the stick. When played as shown in the figure, the rim sound of the connected input is triggered.</p>
<p>Bell shot</p> 	<p>This is the technique of striking the bell. Striking the bell area will produce the rim sound of the connected trigger input. Strike using the shoulder of the stick.</p>
<p>Choke play</p>  <p>Edge sensor</p> <p>Sensor</p>	<p>If you use your hand to choke (grasp) the edge sensor after striking the cymbal, the sound stops. In addition, placing your hand on the sensor will also stop the sound (mute). If you strike the cymbal in a choked or mute state, it rings a shorter time.</p>

Main Specifications

Roland CY-18DR: V-Cymbal Digital Ride

Size	18 inches
Triggers	3 (Bow/Bell/Edge)
Connector	DIGITAL TRIGGER OUT connector (compatible with Roland drum sound module equipped with DIGITAL TRIGGER IN port)
Power Supply	DIGITAL TRIGGER bus power (DC 5 V)
Current draw	90 mA
Dimensions	470 (W) x 470 (D) x 55 (H) mm 18-9/16 (W) x 18-9/16 (D) x 2-3/16 (H) inches
Weight	2.1 kg / 4 lbs 11 oz
Accessories	Owner's manual, Wing nut, Felt washer, Stopper, Connection cable, Cable tie
Options (sold separately)	Cymbal mount (MDY series) Cymbal parts set (CYM-10)

* This document explains the specifications of the product at the time that the document was issued. For the latest information, refer to the Roland website.

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠️ **WARNING** and ⚠️ **CAUTION** Notices

⚠️ WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠️ CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

⚠️	The ⚠️ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
ⓧ	The ⓧ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
⚡	The ⚡ symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

⚠️ WARNING

Do not disassemble or modify by yourself

Do not carry out anything unless you are instructed to do so in the owner's manual. Otherwise, you risk causing malfunction.



Do not repair or replace parts by yourself

Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information."



Do not use or store in the following types of locations

- Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
- Damp (e.g., baths, washrooms, on wet floors); or are
- Exposed to steam or smoke; or are
- Subject to salt exposure; or are
- Exposed to rain; or are
- Dusty or sandy; or are
- Subject to high levels of vibration and shakiness; or are
- Placed in a poorly ventilated location.



⚠️ WARNING

Use only the stand that is recommended

This unit should be used only with a stand that is recommended by Roland.



Do not place in a location that is unstable

When using the unit with a stand recommended by Roland, the stand must be carefully placed so it is level and sure to remain stable. If not using a stand, you still need to make sure that any location you choose for placing the unit provides a level surface that will properly support the unit, and keep it from wobbling.



Do not allow foreign objects or liquids to enter unit; never place containers with liquid on unit

Do not place containers containing liquid (e.g., flower vases) on this product. Never allow foreign objects (e.g., flammable objects, coins, wires) or liquids (e.g., water or juice) to enter this product. Doing so may cause short circuits, faulty operation, or other malfunctions.



⚠️ WARNING

Turn off the unit if an abnormality or malfunction occurs

Immediately turn the unit off, and request servicing by your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" when:



- If smoke or unusual odor occurs; or
- Objects have fallen into, or liquid has been spilled onto the unit; or
- The unit has been exposed to rain (or otherwise has become wet); or
- The unit does not appear to operate normally or exhibits a marked change in performance.

Be cautious to protect children from injury

Always make sure that an adult is on hand to provide supervision and guidance when using the unit in places where children are present, or when a child will be using the unit.



Do not drop or subject to strong impact

Otherwise, you risk causing damage or malfunction.



⚠️ CAUTION

Use only the specified stand(s)

This unit is designed to be used in combination with specific stands (Roland MDS series) manufactured by Roland. If used in combination with other stands, you risk sustaining injuries as the result of this product dropping down or toppling over due to a lack of stability.



Evaluate safety issues before using stands

Even if you observe the cautions given in the owner's manual, certain types of handling may allow this product to fall from the stand, or cause the stand to overturn. Please be mindful of any safety issues before using this product.



Route all power cords and cables in such a way as to prevent them from getting entangled

Injury could result if someone were to trip on a cable and cause the unit to fall or topple.



Avoid climbing on top of the unit, or placing heavy objects on it

Otherwise, you risk injury as the result of the unit toppling over or dropping down.



Disconnect all cords/cables before moving the unit

Damage or malfunction may result if you fail to disconnect all cables before moving the unit.



Keep small items out of the reach of children

To prevent accidental ingestion of the parts listed below, always keep them out of the reach of small children.



Removable Parts:

- Stopper
- Stopper bolt
- Wing nut
- Felt washer

IMPORTANT NOTES

Placement

- This unit may interfere with radio and television reception. Do not use this unit in the vicinity of such receivers.
- When moved from one location to another where the temperature and/or humidity is very different, water droplets (condensation) may form inside the unit. Damage or malfunction may result if you attempt to use the unit in this condition. Therefore, before using the unit, you must allow it to stand for several hours, until the condensation has completely evaporated.
- Do not place containers or anything else containing liquid on top of this unit. Also, whenever any liquid has been spilled on the surface of this unit, be sure to promptly wipe it away using a soft, dry cloth.

Maintenance

- Never use benzene, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

Additional Precautions

- Use a reasonable amount of care when using the unit's buttons, sliders, or other controls; and when using its jacks and connectors. Rough handling can lead to malfunctions.
- When disconnecting all cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.
- This instrument is designed to minimize the extraneous sounds produced when it's played. However, since sound vibrations can be transmitted through floors and walls to a greater degree than expected, take care not to allow these sounds to become a nuisance others nearby.
- The rubber portion of the striking surface is treated with a preservative to maintain its performance. With the passage of time, this preservative may appear on the surface as a white stain, or reveal how the pads were struck during product testing. This does not affect the performance or functionality of the product, and you may continue using it with confidence.
- Continuous playing may cause discoloration of the pad, but this will not affect the pad's function.

Intellectual Property Right

- MMP (Moore Microprocessor Portfolio) refers to a patent portfolio concerned with microprocessor architecture, which was developed by Technology Properties Limited (TPL). Roland has licensed this technology from the TPL Group.
- Roland and V-Drums are either registered trademarks or trademarks of Roland Corporation in the United States and/or other countries.
- Company names and product names appearing in this document are registered trademarks or trademarks of their respective owners.