

User Manual

Harley Benton

Powerplant Junior

Power Supply

Thomann GmbH

Hans-Thomann-Straße 1

96138 Burgebrach

Germany

Telephone: +49 (0) 9546 9223-0

Internet: www.thomann.de

13.09.2022, ID: 264101 (V3)

Table of contents

1	General information.....	5
	1.1 Further information.....	6
	1.2 Symbols and signal words.....	6
2	Safety instructions.....	8
3	Installation and starting up.....	10
4	Components and functions.....	14
5	Technical specifications.....	15
6	Protecting the environment.....	17



1 General information

This user manual contains important information on the safe operation of the device. Read and follow all safety notes and all instructions. Save this manual for future reference. Make sure that it is available to all persons using this device. If you sell the device to another user, be sure that they also receive this manual.

Our products and user manuals are subject to a process of continuous development. We therefore reserve the right to make changes without notice. Please refer to the latest version of the user manual which is ready for download under www.thomann.de.



1.1 Further information

On our website (www.thomann.de) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

1.2 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – high-voltage.
	Warning – danger zone.

2 Safety instructions

Intended use

This device transforms mains voltage into safety extra-low voltage, e.g. for the voltage supply of effects pedals. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Safety



DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard! Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke! Never let children unattended use electrical devices.



DANGER!

Electric shock caused by high voltages inside

Within the device there are areas where high voltages may be present. Never remove any covers. There are no user-serviceable parts inside. Do not use the device if covers, protectors or optical components are missing or damaged.

**DANGER!****Electric shock caused by short-circuit**

Always use proper ready-made insulated mains cabling (power cord) with a protective contact plug. Do not modify the mains cable or the plug. Failure to do so could result in electric shock/death or fire. If in doubt, seek advice from a registered electrician.

**NOTICE!****Operating conditions**

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations. Only operate the device within the ambient conditions specified in the chapter 'Technical specifications' of this user manual. Avoid heavy temperature fluctuations and do not switch the device on immediately after it was exposed to temperature fluctuations (for example after transport at low outside temperatures). Dust and dirt inside can damage the unit. When operated in harmful ambient conditions (dust, smoke, nicotine, fog, etc.), the unit should be maintained by qualified service personnel at regular intervals to prevent overheating and other malfunction.

**NOTICE!****Power supply**

Before connecting the device, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly injure the user. Unplug the device before electrical storms occur and when it is unused for long periods of time to reduce the risk of electric shock or fire.

**NOTICE!****Possible staining**

The plasticiser contained in the rubber feet of this product may possibly react with the coating of your surface and after some time cause permanent dark stains. In case of doubt, do not put the rubber feet directly on the surface and use a suitable underlay if necessary, i.e. felt pads or similar.

3 Installation and starting up

Unpack and check carefully there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the product against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

Wiring


Create all connections while the device is not connected to the mains. Use the supplied cables for all connections.

The following cable types are available:

- 5 standard cables (1:1), length 30 cm, each to supply one effects pedal
- 5 standard cables (1:1), length 60 cm, each to supply one effects pedal
- 1 Y-cable to supply one effects pedal with higher power consumption
- 1 serial cable to supply a maximum of 5 effects devices from one 9 V output socket of the power supply


1:1 Wiring

Connect – as shown in the drawing – one plug of the standard cable to the 9 V power supply input of an effects pedal, the other plug to a 9 V output socket of the power supply. In order to avoid an overload of the power supply, the current draw of each connected pedal must not exceed 120 mA.




Y-cable for devices with higher power consumption

Connect – as shown in the drawing – the single plug to the 9 V power supply input of an effects pedal, the plug pair of the Y-cable to two 9 V output sockets of the power supply. In order to avoid an overload of the power supply, the current draw of the effects pedal must not exceed 240 mA.




Serial cable

The serial cable is used to power several effects pedals standing next to each other in a clear way. Connect – as shown in the drawing – the five output plugs of the cable to the power input of the effects pedals, the input plug of the cable to a 9 V output socket of the power supply. The total current draw of all effects devices connected via the serial cable must not exceed 120 mA; thus leaving a maximum of 24 mA to each effects pedal when using devices of the same kind.



4 Components and functions



1...5 Output sockets for 9 V ---

6 Red control light. Indicates that the device is connected to the power supply.

5 Technical specifications

Output connections	Effects Pedal	5 × output socket
Supply voltage		230 V ~ 50 Hz
Current consumption		30 mA
Power consumption		1.54 W
Output voltage		5 × 9 V $\overline{\text{=}}$ (DC)
Dimensions (W × H × D)		116 mm × 38 mm × 77 mm
Weight		920 g
Ambient conditions	Temperature range	0 °C...40 °C
	Relative humidity	20 %...80 % (non-condensing)

Further information

9 V	yes
12 V	no
18 V	no
Other secondary voltage	no
DC/AC current	AC/DC
Multi-power supply	yes

6 Protecting the environment

Disposal of the packaging material



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

Disposal of your old device



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE) in its currently valid version. Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

